

Date: April 13, 2007

Topic: Instructions to attach BFX adapter to Chrysler and Chevy Minivans



1. Locate brake master cylinder and reservoir (Figure 1).
2. Carefully rotate nozzle toward right (Figure 2).
3. Continue to rotate nozzle until position shown in Figure 3.
4. Pull upward on nozzle to remove from reservoir tank. (Figure 4)
5. Empty and Fill master cylinder using standard procedures.
6. Install appropriate adapter as shown in Figure 5.
7. After service is complete, follow steps in reverse order to reinstall reservoir nozzle.



**Figure 1**



**Figure 2**



**Figure 3**



**Figure 4**



**Figure 5**

### **RTI Technologies, Inc.**

10 Innovation Drive • P.O. Box 3099 - York - PA 17402 - USA  
Toll Free: 800-468-2321 • Phone: 717-840-0678 • Fax: 717-755-8304

[www.rtitech.com](http://www.rtitech.com)

**560-80427-00**

An AGRAWKOW Company