



RTI Technologies, Inc.
AGRAMKOW Fluid Systems A/S
10 Innovation Drive
PO Box 3099
York, Pennsylvania 17402

Phone: 717-840-0678
Extension 233
Fax: 717-755-8304
E-Mail: tlc@rtitech.com
Web Site: www.rtitech.com

April 20, 2005

USE THE DFX-1 ONLY WITH DIFFERENTIAL FLUIDS

The state-of-the-art DFX-1 was designed and tested by RTI to perform differential fluid exchanges. This involved extensive compatibility testing of the two pumps.

Many brands of differential fluids were successfully tested.

Recently there have been some pumps on other equipment which failed and when returned to the factory were found to have seals which had swelled and softened. This clearly indicates that some fluid other than that for which the equipment was designed are being extracted.

The most likely fluid which may have been extracted is brake fluid. This fluid will definitely cause the seals to swell as was observed in the returned pumps.

The RTI warranty for the DFX-1 is voided if any fluid other than differential fluids are used.

If a DFX-1 under warranty is diagnosed by our Technical Support Group as having a malfunctioning pump - a replacement pump must be purchased. The defective pump may be returned to RTI for analysis and the purchase price will be refunded if a manufacturing defect is determined.

Thomas L. Crandall

VP - Technology